




**Controller Option**

KUKA Roboter GmbH

## **Optional Interfaces**

**For KR C4 compact**

**Assembly and Operating Instructions**



Issued: 08.05.2017

Version: MA KR C4 compact Interfaces V12



© Copyright 2017

KUKA Roboter GmbH  
Zugspitzstraße 140  
D-86165 Augsburg  
Germany

This documentation or excerpts thereof may not be reproduced or disclosed to third parties without the express permission of KUKA Roboter GmbH.

Other functions not described in this documentation may be operable in the controller. The user has no claims to these functions, however, in the case of a replacement or service work.

We have checked the content of this documentation for conformity with the hardware and software described. Nevertheless, discrepancies cannot be precluded, for which reason we are not able to guarantee total conformity. The information in this documentation is checked on a regular basis, however, and necessary corrections will be incorporated in the subsequent edition.

Subject to technical alterations without an effect on the function.

Translation of the original documentation

KIM-PS5-DOC

Publication:	Pub MA KR C4 compact Interfaces (PDF) en
Book structure:	MA KR C4 compact Interfaces V11.2
Version:	MA KR C4 compact Interfaces V12

# Contents

<b>1</b>	<b>Introduction</b>	<b>5</b>
1.1	Industrial robot documentation	5
1.2	Representation of warnings and notes	5
1.3	Terms used	6
<b>2</b>	<b>Purpose</b>	<b>7</b>
2.1	Target group	7
2.2	Intended use	7
<b>3</b>	<b>Product description</b>	<b>9</b>
3.1	Description of the industrial robot	9
3.2	Overview of the robot controller	9
3.3	Optional KR C4 compact interfaces	10
3.4	Digital I/O modules and bus coupler	13
3.4.1	Digital I/O modules 16/16	13
3.4.2	Digital I/O modules 16/16/4	14
3.5	External 24 V power supply	14
<b>4</b>	<b>Technical data</b>	<b>17</b>
4.1	External 24 V power supply	17
4.2	IOB board	17
<b>5</b>	<b>Safety</b>	<b>19</b>
<b>6</b>	<b>Planning</b>	<b>21</b>
6.1	Discrete interfaces for safety options	21
6.1.1	Reference switch X42	21
6.2	External power supplies	22
6.2.1	X55 External power supply	22
6.3	EtherCAT interfaces	23
6.3.1	X67.1 and X67.2 EtherCAT bridge interfaces	23
6.3.2	X14 DeviceNet interfaces, overview	24
6.3.2.1	X14A DeviceNet master	24
6.3.2.2	X14C and X14D DeviceNet interface	25
6.4	EtherCAT input/output modules	26
6.4.1	Digital I/O interfaces	26
6.4.1.1	Digital I/O modules 16/16	26
6.4.1.2	Digital I/O modules 16/16/4	28
6.4.1.3	16-channel inputs EL1889, negative switching	31
6.4.1.4	16-channel outputs EL2889, negative switching	32
6.4.1.5	X12 IO digital I/O interfaces 16/16 or 16/16/4	32
6.4.2	X12 IOB digital I/O interfaces	33
6.5	PROFIBUS interfaces	37
6.5.1	X15A and X15B PROFIBUS interface	37
6.5.2	X61 PROFIBUS master	39
6.6	Euromap interfaces	39
6.6.1	X67.1 and X67.2 VARAN slave interfaces	39
6.7	Fast Measurement	40
6.7.1	X33 Fast Measurement inputs	40

6.7.1.1	Power supply for Fast Measurement .....	41
6.7.2	X60 PickControl interface .....	42
6.7.2.1	Power supply for Fast Measurement X60 .....	43
6.8	X28 Drive box interface for external axes interface .....	44
6.9	X70 and X71 RoboTeam interface .....	44
6.10	Performance level .....	45
6.10.1	PFH values of the safety functions .....	45
<b>7</b>	<b>Troubleshooting</b> .....	<b>47</b>
7.1	IOB board LED display .....	47
<b>8</b>	<b>KUKA Service</b> .....	<b>49</b>
8.1	Requesting support .....	49
8.2	KUKA Customer Support .....	49
	<b>Index</b> .....	<b>57</b>

# 1 Introduction

## 1.1 Industrial robot documentation

The industrial robot documentation consists of the following parts:


- Documentation for the manipulator
- Documentation for the robot controller
- Operating and programming instructions for the System Software
- Instructions for options and accessories
- Parts catalog on storage medium


Each of these sets of instructions is a separate document.


## 1.2 Representation of warnings and notes


### Safety


These warnings are relevant to safety and **must** be observed.

 **DANGER** These warnings mean that it is certain or highly probable that death or severe injuries **will** occur, if no precautions are taken.


 **WARNING** These warnings mean that death or severe injuries **may** occur, if no precautions are taken.

 **CAUTION** These warnings mean that minor injuries **may** occur, if no precautions are taken.

 **NOTICE** These warnings mean that damage to property **may** occur, if no precautions are taken.

 These warnings contain references to safety-relevant information or general safety measures.  
These warnings do not refer to individual hazards or individual precautionary measures.


This warning draws attention to procedures which serve to prevent or remedy emergencies or malfunctions:

 **SAFETY INSTRUCTIONS** The following procedure must be followed exactly!

Procedures marked with this warning **must** be followed exactly.

### Notices

These notices serve to make your work easier or contain references to further information.

 Tip to make your work easier or reference to further information.

### 1.3 Terms used

Term	Description
CIP Safety	<b>Common Industrial Protocol Safety</b> CIP Safety is an Ethernet/IP-based safety interface for connecting a safety PLC to the robot controller. (PLC = master, robot controller = slave)
CCU_SR	<b>Cabinet Control Unit Small Robot</b>
CIB_SR	<b>Cabinet Interface Board Small Robot</b>
Dual NIC card	Dual network card
EDS	<b>Electronic Data Storage</b> (memory card)
EMD	<b>Electronic Mastering Device</b>
EMC	Electromagnetic compatibility
KCB	<b>KUKA Controller Bus</b>
KEB	<b>KUKA Extension Bus</b>
KEI	<b>KUKA Extension Interface</b>
KLI	<b>KUKA Line Interface</b> . Connection to higher-level control infrastructure (PLC, archiving)
KOI	<b>KUKA Option Interface</b>
KONI	<b>KUKA Option Network Interface</b>
KPC	Control PC
KPP_SR	<b>KUKA Power Pack Small Robot</b>
KRL	KUKA robot programming language ( <b>KUKA Robot Language</b> )
KSB	<b>KUKA System Bus</b> . Internal KUKA bus for internal networking of the controllers with each other
KSI	<b>KUKA Service Interface</b>
KSP_SR	<b>KUKA Servo Pack Small Robot</b>
KSS	<b>KUKA System Software</b>
Manipulator	The robot arm and the associated electrical installations
PMB_SR	<b>Power Management Board Small Robot</b>
RDC	<b>Resolver Digital Converter</b>
SATA connections	Data bus for exchanging data between the processor and the hard drive
USB	<b>Universal Serial Bus</b> . Bus system for connecting additional devices to a computer
EA	External axis (linear unit, Posiflex)

## 2 Purpose

### 2.1 Target group

This documentation is aimed at users with the following knowledge and skills:

- Advanced knowledge of electrical and electronic systems
- Advanced knowledge of the robot controller
- Advanced knowledge of the Windows operating system



For optimal use of our products, we recommend that our customers take part in a course of training at KUKA College. Information about the training program can be found at [www.kuka.com](http://www.kuka.com) or can be obtained directly from our subsidiaries.

### 2.2 Intended use

#### Use

The following interfaces are options for the KR C4 compact robot controller:

- X61 PROFIBUS master
  - Optionally expandable with X12 digital inputs and outputs 16/16
  - Optionally expandable with X60 PickControl
  - Optionally expandable with X42 mastering test
- X15A and X15B PROFIBUS slave IN and OUT
  - Optionally expandable with X12 digital inputs and outputs 16/16
  - Optionally expandable with X60 PickControl
- X14A DeviceNet master
  - Optionally expandable with X12 digital inputs and outputs 16/16
  - Optionally expandable with X60 PickControl
- X14C and X14D DeviceNet slave
  - Optionally expandable with X12 digital inputs and outputs 16/16
  - Optionally expandable with X60 PickControl
- X61 with X15A and X15B PROFIBUS master with PROFIBUS slave IN and OUT
- X14A with X14C and X14D DeviceNet master with DeviceNet slave
- X12 digital inputs and outputs 16/16
  - Optionally expandable with X60 PickControl
  - Optionally expandable with X42 mastering test
- X12 digital inputs and outputs 16/16/4
  - Optionally expandable with X42 mastering test
- X55 external power supply
- X33 Fast Measurement
- X42 reference switch
- X67.1 and X67.2 EtherCAT bridge master/master
- X67.1 and X67.2 VARAN slave EtherCAT IN/OUT
- X70 and X71 RoboTeam input and output
- X28 drive box interface for external axes
- X60 PickControl
  - Optionally expandable with X12 digital inputs and outputs 16/16
  - Optionally expandable with X42 mastering test

**Misuse**

Any use or application deviating from the intended use is deemed to be misuse and is not allowed. This includes e.g.:

- Use as a climbing aid
- Operation outside the permissible operating parameters
- Use in potentially explosive environments
- Use in underground mining




## 3 Product description

### 3.1 Description of the industrial robot

The industrial robot consists of the following components:

- Manipulator
- Robot controller
- smartPAD teach pendant
- Connecting cables
- Software
- Options, accessories



**Fig. 3-1: Example of an industrial robot**

- |   |                               |
|---|-------------------------------|
| 1 | Manipulator                   |
| 2 | Control panel                 |
| 3 | Connecting cable for smartPAD |
| 4 | Robot controller              |
| 5 | Connecting cable, data cable  |
| 6 | Connecting cable, motor cable |
| 7 | Device connection cable       |

### 3.2 Overview of the robot controller


The robot controller is used for controlling the following systems:

- KUKA small robots

The robot controller consists of the following components:

- Control PC
- Power unit
- Safety logic
- smartPAD teach pendant
- Connection panel

The robot controller can be installed in a 19" rack.



**Fig. 3-2: Overview of KR C4 compact**

- 1 Control unit (control box)
- 2 Power unit (drive box)

### 3.3 Optional KR C4 compact interfaces


#### Overview

The connection panel of the robot controller consists of connections for the following cables:

- Power cable / infeed
- Motor cables to the manipulator
- Data cables to the manipulator
- KUKA smartPAD cable
- PE cables
- Peripheral cables

The configuration of the connection panel varies according to the customer-specific version and the options required.

#### Connection panel



**Fig. 3-3: Connection panel**

- 1 Slot 1
- 2 Slot 2
- 3 X42 reference switch

- 4 X55 external power supply interface
- 5 Slot 4
- 6 X12 interface with IOB-16-16B
- 7 X28 drive box interface for external axes
- 8 X12 Beckhoff interface, digital I/O





All contactor, relay and valve coils that are connected to the robot controller by the user must be equipped with suitable suppressor diodes. RC elements and VCR resistors are not suitable.

### Assignment of slot 1






Slot 1 can be assigned the following interfaces:

Slot	Connector	Description	Comment
	X61	PROFIBUS master	X61 can be selected individually.
	X15A	PROFIBUS slave IN	-
	X15B	PROFIBUS slave OUT	-
	X61	PROFIBUS master	X61 can be selected individually.
	X60	PickControl	-
	X61	PROFIBUS master	X61 can be selected individually.
	X42	Mastering test	-
	X61	PROFIBUS master	X61 can be selected individually.
	X60	PickControl	-
	X42	Mastering test	-
	X60	PickControl	X60 can be selected individually.
	X15A	PROFIBUS slave IN	-
	X15B	PROFIBUS slave OUT	-
	X14A	DeviceNet master	X14A can be selected individually.
	X14C	DeviceNet slave IN	-
	X14D	DeviceNet slave OUT	-
	X60	PickControl	X60 can be selected individually.
	X14A	DeviceNet master	-
	X60	PickControl	X60 can be selected individually.
	X14C	DeviceNet slave IN	-
	X14D	DeviceNet slave OUT	-

Slot	Con- nec- tor	Description	Comment
	X60	PickControl	X60 can be selected individually.
	X42	Mastering test	-
	X67.1	<ul style="list-style-type: none"> <li>VARAN slave EtherCAT</li> <li>EtherCAT bridge (master/master)</li> </ul>	Signal IN
	X67.2	<ul style="list-style-type: none"> <li>VARAN slave EtherCAT</li> <li>EtherCAT bridge (master/master)</li> </ul>	Signal OUT

### Assignment of slot 2

Slot 2 can be assigned the following interfaces:

Slot	Con- nec- tor	Description	Comment
	X15A	PROFIBUS slave IN	-
	X15B	PROFIBUS slave OUT	-
	X60	PickControl	-
	X60	PickControl	X60 can be selected individually.
	X42	Mastering test	-
	X14C	DeviceNet slave IN	-
	X14D	DeviceNet slave OUT	-
	X14A	DeviceNet master	-

### Combinations

The following combinations of interfaces are possible:

PROFIBUS:

- X61 with X55
- X61 with X55 and X12
- X61 with X55 and X60
- X61 with X55 and X42
- X61 with X15A/X15B and X55
- X15A/X15B with X55
- X15A/X15B with X55 and X12
- X15A/X15B with X55 and X60

DeviceNet:

- X14A with X55
- X14A with X55 and X12
- X14A with X55 and X60
- X14A with X14C/X14D and X55
- X14C/X14D with X55



- X14C/X14D with X55 with X12
- X14C/X14D with X55 with X60

External power supplies:

- X55
- X55 with X12 with 16/16 I/Os
- X55 with X12 with 16/16 I/Os and X60
- X55 with X12 with 16/16/4 I/Os
- X55 with X67.1 and X67.2
- X55 with X60
- X55 with X60 and X12 with 16/16 I/Os

#### Assignment of slot 4

Slot 4 can be assigned the following interfaces:

Slot	Con- nec- tor	Description	Comments
	X33	Fast Measurement	-
	X70	RoboTeam input	-
	X71	RoboTeam output	-

### 3.4 Digital I/O modules and bus coupler

#### 3.4.1 Digital I/O modules 16/16

##### Overview

The digital I/O interface 16/16 consists of the following components:

- EtherCAT bus coupler
- EtherCAT 16x input terminal
- EtherCAT 16x output terminal
- EtherCAT bus end cap




Fig. 3-4: Overview of digital modules 16/16

- 1 KEI connection X1
- 2 EK1100 EtherCAT bus coupler A20

- 3 EL1809/ EL1889 input terminal A21
- 4 EL2809/ EL2889 output terminal A22
- 5 EL9011 bus end cap



Detailed information about the EtherCAT bus coupler and the I/O modules can be found in the manual from Beckhoff.

### 3.4.2 Digital I/O modules 16/16/4

#### Overview

The digital I/O interface 16/16/4 consists of the following components:

- EtherCAT bus coupler
- EtherCAT 16x input terminal
- EtherCAT 16x output terminal
- EtherCAT infeed terminal
- EtherCAT 4x output terminal
- EtherCAT bus end cap




Fig. 3-5: Digital module 16/16/4

- 1 KEI connection X1
- 2 EK1100 bus coupler A20
- 3 EL1809/ EL1889 input terminal A21
- 4 EL2809/ EL2889 output terminal A22
- 5 EL9100 infeed terminal A23
- 6 EL2024 output terminal A27
- 7 EL9011 bus end cap



Detailed information about the EtherCAT bus coupler and the I/O modules can be found in the manual from Beckhoff.

## 3.5 External 24 V power supply

External 24 V power supply is possible via interface X55 for the following components:

- Beckhoff digital I/O modules and bus coupler
- VARAN slave





## 4 Technical data

### 4.1 External 24 V power supply

#### PELV external power supply

External voltage	PELV power supply unit acc. to EN 60950 with rated voltage 27 V (18 V ... 30 V), safely isolated
Continuous current	> 8 A
Cable cross-section of power supply cable	$\geq 1 \text{ mm}^2$
Cable length of power supply cable	< 50 m, or < 100 m wire length (outgoing and incoming lines)



The cables of the power supply unit must not be routed together with power-carrying cables.



The minus connection of the external voltage must be grounded by the customer.



Parallel connection of a basic-insulated device is not permitted.

### 4.2 IOB board

#### Inputs

Signal voltage 0	-3 ... +5 V (EN 61131-2, type 1/3)
Signal voltage 1	11 ... 30 V (EN 61131-2, type 3)
Input current	3 mA typ. (EN 61131-2, type 3)
Maximum cable length	50 m wire length (outgoing and incoming lines)

#### Outputs

Output type	High-side and low-side (can be selected for each output)
Voltage	18 ... 30 V
Maximum current	0.5 A for each output
Load type	Ohmic Inductive Lamp load
t_ON	$\leq 100 \text{ } \mu\text{s}$
t_OFF	$\leq 300 \text{ } \mu\text{s}$
Maximum cable length	50 m wire length (outgoing and incoming lines)



## 5 Safety

This documentation contains safety instructions which refer specifically to the product described here. The fundamental safety information for the industrial robot can be found in the “Safety” chapter of the operating or assembly instructions for the robot controller.

**WARNING**

The “Safety” chapter in the operating instructions or assembly instructions of the robot controller must be observed. Death to persons, severe injuries or considerable damage to property may otherwise result.



## 6 Planning

### Overview

Step	Description
1	X42 reference switch (>>> 6.1.1 "Reference switch X42" Page 21)
2	X55 external power supply (>>> 6.2.1 "X55 External power supply " Page 22)
3	X67.1 X67.2 EtherCAT bridge interfaces (>>> 6.3.1 "X67.1 and X67.2 EtherCAT bridge interfaces" Page 23) X14 DeviceNet interfaces (>>> 6.3.2.1 "X14A DeviceNet master" Page 24) (>>> 6.3.2.2 "X14C and X14D DeviceNet interface" Page 25)
4	X12 Digital I/O interfaces (>>> 6.4.1.1 "Digital I/O modules 16/16" Page 26) (>>> 6.4.1.2 "Digital I/O modules 16/16/4" Page 28)
5	X15A and X15B PROFIBUS interface (>>> 6.5.1 "X15A and X15B PROFIBUS interface" Page 37) X61 PROFIBUS master (>>> 6.5.2 "X61 PROFIBUS master" Page 39)
6	X67.1 X67.2 VARAN slave interfaces (>>> 6.6.1 "X67.1 and X67.2 VARAN slave interfaces" Page 39)
7	X33 Fast Measurement inputs (>>> 6.7.1 "X33 Fast Measurement inputs" Page 40) X60 PickControl interface (>>> 6.7.2 "X60 PickControl interface" Page 42)
8	X28 Drive box for external axes interface (>>> 6.8 "X28 Drive box interface for external axes interface" Page 44)
9	RoboTeam interface X70 and X71 (>>> 6.9 "X70 and X71 RoboTeam interface" Page 44)
10	Performance level (>>> 6.10 "Performance level" Page 45)

### 6.1 Discrete interfaces for safety options


#### 6.1.1 Reference switch X42

##### Description

The reference switch is connected to interface X42. The reference switch is needed to carry out the mastering test.



Detailed information about the mastering test can be found in the **KUKA.SafeOperation** documentation.



X42



XS Ref

**Fig. 6-1: Connector pin allocation for reference cable X42 - XS Ref****Connector pin allocation X42**

Pin	Description
1	Test output A 24 V
2	Input A, reference switch 24 V
3	GND
4	Test output B 24 V
5	Input B, reference switch 24 V

**6.2 External power supplies****6.2.1 X55 External power supply****Description**

The power can be supplied either directly from an external source to contacts 3/4 and/or 5/6, or by jumpering the internal voltage (contacts 7/8) on X55.



The 4x2 A output module must only be supplied with power externally to contacts 1/2. The module must not be supplied with power internally.

The following couplers can be supplied with power via connector X55:

- Switch
- EtherCAT bridge
- VARAN slave
- Male insert, HAN 8D

**Necessary equipment****Fig. 6-2: Contact diagram, view from contact side**

- Cable clamping range: Ø9 ... Ø13 mm
- Recommended wire cross-section: 1 mm<sup>2</sup>

**Connector pin  
allocation X55  
with bus coupler**

Pin	Description
1	+24 V external
2	0 V external
3	+24 V external
4	0 V external
5	+24 V external
6	0 V external
7	24 V internal
8	0 V internal
-	PE

**Connector pin  
allocation X55  
with EtherCAT  
bridge**

Pin	Description
1	+24 V external
2	0 V external
3	+24 V external
4	0 V external
5	+24 V external
6	0 V external
7	24 V internal
8	0 V internal
-	PE

**Connector pin  
allocation X55  
with VARAN slave**

Pin	Description
5	+24 V external
6	0 V external
7	+24 V internal
8	0 V internal
-	PE


## 6.3 EtherCAT interfaces

### 6.3.1 X67.1 and X67.2 EtherCAT bridge interfaces

**Description** EtherCAT bridge interfaces X67.1 and X67.2 enable communication between an EtherCat master and the robot controller via the EtherCat bridge.

**Necessary equipment**

- Connector V14 RJ45



**Fig. 6-3: RJ-45 pin assignment**

- Recommended connecting cable: Ethernet-compatible, min. category CAT 5e
- Maximum cable cross-section: AWG22

**Connector pin allocation X67.1**

Pin	Description
1	TD+ Master IN
2	TD- Master IN
3	RD+ Master IN
6	RD- Master IN
-	PE

**Connector pin allocation X67.2**

Pin	Description
1	TD+ Master OUT
2	TD- Master OUT
3	RD+ Master OUT
6	RD- Master OUT
-	PE

### 6.3.2 X14 DeviceNet interfaces, overview

**Description**

DeviceNet enables the communication between the robot controller and the external periphery.

The following DeviceNet variants are available:


- X14A DeviceNet master
- X14C DeviceNet slave IN  
X14D DeviceNet slave OUT
- X14A DeviceNet master  
X14C DeviceNet slave IN  
X14D DeviceNet slave OUT

#### 6.3.2.1 X14A DeviceNet master

**Necessary equipment**

- Male connector, 5-pole





**Fig. 6-4: Contact diagram, X14A, view from contact side**

- Cable clamping range: Ø10 ... Ø12 mm
- Recommended connecting cable: DeviceNet cable 2xAWG17, 2xAWG20, drain AWG20


#### Connector pin allocation X14A

Pin	Description
1	DRAIN
2	+24 V
3	0 V
4	CAN_H
5	CAN_L

#### 6.3.2.2 X14C and X14D DeviceNet interface


##### Necessary equipment

- Female connector, 5-pole



**Fig. 6-5: Contact diagram, X14C, view from contact side**

- Cable clamping range: Ø10 ... Ø12 mm
- Recommended connecting cable: DeviceNet cable 2xAWG17, 2xAWG20, drain AWG20
- Male connector, 5-pole



**Fig. 6-6: Contact diagram, X14D, view from contact side**

- Cable clamping range: Ø10 ... Ø12 mm

- Recommended connecting cable: DeviceNet cable 2xAWG17, 2xAWG20, drain AWG20

#### Connector pin allocation X14C

Pin	Description
1	DRAIN
2	+24 V
3	0 V
4	CAN_H
5	CAN_L

#### Connector pin allocation X14D

Pin	Description
1	DRAIN
2	+24 V
3	0 V
4	CAN_H
5	CAN_L

## 6.4 EtherCAT input/output modules



The EtherCAT devices must be configured with WorkVisual.

### 6.4.1 Digital I/O interfaces

#### 6.4.1.1 Digital I/O modules 16/16

##### Overview of 16-channel inputs




Fig. 6-7: Connections, 16-channel inputs

### Connections, 16-channel inputs

Signal	Item	Description	
Input 1	1	Digital input 1	EL1809: Reference point 0 V external 1-16
Input 2	2	Digital input 2	
Input 3	3	Digital input 3	
Input 4	4	Digital input 4	
Input 5	5	Digital input 5	EL1889: Reference point 24 V external 1-16
Input 6	6	Digital input 6	
Input 7	7	Digital input 7	
Input 8	8	Digital input 8	
Input 9	9	Digital input 9	
Input 10	10	Digital input 10	
Input 11	11	Digital input 11	
Input 12	12	Digital input 12	
Input 13	13	Digital input 13	
Input 14	14	Digital input 14	
Input 15	15	Digital input 15	
Input 16	16	Digital input 16	

### Overview of 16-channel 0.5 A outputs




Fig. 6-8: Connections, 16-channel 0.5 A outputs

### Connections, 16-channel 0.5 A outputs

Signal	Item	Description	
Output 1	1	Digital output 1	EL2809: 0.5 A per output, 24 V external power supply 1-16
Output 2	2	Digital output 2	
Output 3	3	Digital output 3	
Output 4	4	Digital output 4	
Output 5	5	Digital output 5	EL2889: 0.5 A per output, 0 V external power supply 1-16
Output 6	6	Digital output 6	
Output 7	7	Digital output 7	
Output 8	8	Digital output 8	
Output 9	9	Digital output 9	
Output 10	10	Digital output 10	
Output 11	11	Digital output 11	
Output 12	12	Digital output 12	
Output 13	13	Digital output 13	
Output 14	14	Digital output 14	
Output 15	15	Digital output 15	
Output 16	16	Digital output 16	



If the internal power supply is used, the reference potentials can be tapped at interface X55.

### 6.4.1.2 Digital I/O modules 16/16/4

#### Overview of 16-channel inputs




Fig. 6-9: Connections, 16-channel inputs

### Connections, 16-channel inputs

Signal	Item	Description	
Input 1	1	Digital input 1	EL1809: Reference point 0 V external 1-16
Input 2	2	Digital input 2	
Input 3	3	Digital input 3	
Input 4	4	Digital input 4	
Input 5	5	Digital input 5	EL1889: Reference point 24 V external 1-16
Input 6	6	Digital input 6	
Input 7	7	Digital input 7	
Input 8	8	Digital input 8	
Input 9	9	Digital input 9	
Input 10	10	Digital input 10	
Input 11	11	Digital input 11	
Input 12	12	Digital input 12	
Input 13	13	Digital input 13	
Input 14	14	Digital input 14	
Input 15	15	Digital input 15	
Input 16	16	Digital input 16	

### Overview of 16-channel 0.5 A outputs




Fig. 6-10: Connections, 16-channel 0.5 A outputs

### Connections, 16-channel 0.5 A outputs

Signal	Item	Description	
Output 1	1	Digital output 1	EL2809: 0.5 A per output, 24 V external power supply 1-16
Output 2	2	Digital output 2	
Output 3	3	Digital output 3	
Output 4	4	Digital output 4	
Output 5	5	Digital output 5	EL2889: 0.5 A per output, 0 V external power supply 1-16
Output 6	6	Digital output 6	
Output 7	7	Digital output 7	
Output 8	8	Digital output 8	
Output 9	9	Digital output 9	
Output 10	10	Digital output 10	
Output 11	11	Digital output 11	
Output 12	12	Digital output 12	
Output 13	13	Digital output 13	
Output 14	14	Digital output 14	
Output 15	15	Digital output 15	
Output 16	16	Digital output 16	

### Overview of 4-channel 2 A outputs




Fig. 6-11: Connections, 4-channel 2 A outputs

### Connections, 4-channel 2 A outputs

Signal	Item	Description	
Output 17	1	Digital output 17	2 A per output, 24 V external power supply 17-20
0 V	2	0 V	
0 V	3	0 V	
Output 19	4	Digital output 19	
Output 18	5	Digital output 18	
0 V	6	0 V	
0 V	7	0 V	
Output 20	8	Digital output 20	



If the internal power supply is used, the reference potentials can be tapped at interface X55.

### 6.4.1.3 16-channel inputs EL1889, negative switching

#### Overview




Fig. 6-12: Connections, 16-channel inputs

Signal	Item	Description	
Input 1	1	Digital input 1	Reference point 24 V external 1-16
Input 2	2	Digital input 2	
Input 3	3	Digital input 3	
Input 4	4	Digital input 4	
Input 5	5	Digital input 5	
Input 6	6	Digital input 6	
Input 7	7	Digital input 7	
Input 8	8	Digital input 8	
Input 9	9	Digital input 9	
Input 10	10	Digital input 10	
Input 11	11	Digital input 11	
Input 12	12	Digital input 12	
Input 13	13	Digital input 13	
Input 14	14	Digital input 14	
Input 15	15	Digital input 15	
Input 16	16	Digital input 16	

#### 6.4.1.4 16-channel outputs EL2889, negative switching

##### Overview




Fig. 6-13: Connections, 16-channel 0.5 A outputs

Signal	Item	Description	
Output 1	1	Digital output 1	0.5 A per output, 0 V external power supply 1-16
Output 2	2	Digital output 2	
Output 3	3	Digital output 3	
Output 4	4	Digital output 4	
Output 5	5	Digital output 5	
Output 6	6	Digital output 6	
Output 7	7	Digital output 7	
Output 8	8	Digital output 8	
Output 9	9	Digital output 9	
Output 10	10	Digital output 10	
Output 11	11	Digital output 11	
Output 12	12	Digital output 12	
Output 13	13	Digital output 13	
Output 14	14	Digital output 14	
Output 15	15	Digital output 15	
Output 16	16	Digital output 16	

#### 6.4.1.5 X12 IO digital I/O interfaces 16/16 or 16/16/4

##### Description

The I/O interface X12 has 16 non-safe inputs, 16 non-safe NPN outputs or 16 non-safe PNP outputs.

##### Necessary equipment

- D-Sub connector IP67 50-pole




Fig. 6-14: Contact diagram, view from connection side

- Outer diameter of cable: max. 14 mm
- Recommended wire cross-section: AWG 20 (0.75 mm<sup>2</sup>)



**Connector pin allocation X12**


Pin	Description	Function
1	Digital input 1	EL1809: Reference point 0 V external 1-16
2	Digital input 2	
3	Digital input 3	EL1889: Reference point 24 V external 1-16
4	Digital input 4	
5	Digital input 5	
6	Digital input 6	
7	Digital input 7	
8	Digital input 8	
9	Digital input 9	
10	Digital input 10	
11	Digital input 11	
12	Digital input 12	
13	Digital input 13	
14	Digital input 14	
15	Digital input 15	
16	Digital input 16	
17	Digital output 1	EL2809: 0.5 A per output, 24 V external power supply 1-16
18	Digital output 2	
19	Digital output 3	EL2889: 0.5 A per output, 0 V external power supply 1-16
20	Digital output 4	
21	Digital output 5	
22	Digital output 6	
23	Digital output 7	
24	Digital output 8	
25	Digital output 9	
26	Digital output 10	
27	Digital output 11	
28	Digital output 12	
29	Digital output 13	
30	Digital output 14	
31	Digital output 15	
32	Digital output 16	
33	Digital output 17	2 A per output, 24 V external power supply 17-20
34	0 V reference point	
35	0 V reference point	Option
36	Digital output 19	
37	Digital output 18	
38	0 V reference point	
39	0 V reference point	
40	Digital output 20	

**6.4.2 X12 IOB digital I/O interfaces****Description**

The I/O interface X12 IOB has 16 non-safe inputs, 16 non-safe NPN outputs and 16 non-safe PNP outputs. The component is powered via a 27 V power supply or externally via an X55 jumper plug (>>> 6.2.1 "X55 External power supply " Page 22).

### Necessary equipment

- D-Sub connector IP67 50-pole



**Fig. 6-15: Contact diagram, view from connection side**

- Outer diameter of cable: max. 14 mm
- Recommended wire cross-section: AWG 20 (0.75 mm<sup>2</sup>)

### Connector pin allocation X12 IOB

Pin	Description	Function
1	Digital input 1	Reference point 0 V
2	Digital input 2	
3	Digital input 3	
4	Digital input 4	
5	Digital input 5	
6	Digital input 6	
7	Digital input 7	
8	Digital input 8	
9	Digital input 9	
10	Digital input 10	
11	Digital input 11	
12	Digital input 12	
13	Digital input 13	
14	Digital input 14	
15	Digital input 15	
16	Digital input 16	
17	Digital output 17 high-side	24 V switching
18	Digital output 18 high-side	
19	Digital output 19 high-side	
20	Digital output 20 high-side	
21	Digital output 21 high-side	
22	Digital output 22 high-side	
23	Digital output 23 high-side	
24	Digital output 24 high-side	
25	Digital output 25 high-side	
26	Digital output 26 high-side	
27	Digital output 27 high-side	
28	Digital output 28 high-side	
29	Digital output 29 high-side	
30	Digital output 30 high-side	
31	Digital output 31 high-side	
32	Digital output 32 high-side	
33	GND	max. 4A fuse (FH12-N)

Pin	Description	Function
34	Digital output 1 low-side	0 V switching
35	Digital output 2 low-side	
36	Digital output 3 low-side	
37	Digital output 4 low-side	
38	Digital output 5 low-side	
39	Digital output 6 low-side	
40	Digital output 7 low-side	
41	Digital output 8 low-side	
42	Digital output 9 low-side	
43	Digital output 10 low-side	
44	Digital output 11 low-side	
45	Digital output 12 low-side	
46	Digital output 13 low-side	
47	Digital output 14 low-side	
48	Digital output 15 low-side	
49	Digital output 16 low-side	
50	External power supply	24 V, 4A fuse (FH12-P)



The external power supply (at pins 50 and 33) is protected with a 4 A fuse (FH-12-P, FH-12-N).



The maximum current for the customer outputs for internal or external power supply must not exceed a total of 10 A.


#### Conversion to NPN character

The following measures must be taken in order for the IOB to be able to process inputs (pins 1 - 16) with NPN character (reference point 24 V):



The inputs of the IOB are displayed inverted on the smartPAD.

Pin	connected via	to pin
1	R1	50 (PSUP27V0_EXT)
2	R2	
3	R3	
4	R4	
5	R5	
6	R6	
7	R7	
8	R8	
9	R9	
10	R10	
11	R11	
12	R12	
13	R13	
14	R14	
15	R15	
16	R16	



**Fig. 6-16: X12 with NPN character**

The resistance value per input channel must have the following characteristics:

Resistance value	2.0 kΩ
Tolerance	< 10%
Power	≥ 0.5 W

#### Connector pin allocation X12 IOB

Connector pin allocation X12 IOB with NPN character:

Pin	Description	Function
1	Digital input 1	Reference point 24 V
2	Digital input 2	
3	Digital input 3	
4	Digital input 4	
5	Digital input 5	
6	Digital input 6	
7	Digital input 7	
8	Digital input 8	
9	Digital input 9	
10	Digital input 10	
11	Digital input 11	
12	Digital input 12	
13	Digital input 13	
14	Digital input 14	
15	Digital input 15	
16	Digital input 16	

Pin	Description	Function
17	Digital output 17 high-side	24 V switching
18	Digital output 18 high-side	
19	Digital output 19 high-side	
20	Digital output 20 high-side	
21	Digital output 21 high-side	
22	Digital output 22 high-side	
23	Digital output 23 high-side	
24	Digital output 24 high-side	
25	Digital output 25 high-side	
26	Digital output 26 high-side	
27	Digital output 27 high-side	
28	Digital output 28 high-side	
29	Digital output 29 high-side	
30	Digital output 30 high-side	
31	Digital output 31 high-side	
32	Digital output 32 high-side	
33	GND	max. 4A fuse (FH12-N)
34	Digital output 1 low-side	0 V switching
35	Digital output 2 low-side	
36	Digital output 3 low-side	
37	Digital output 4 low-side	
38	Digital output 5 low-side	
39	Digital output 6 low-side	
40	Digital output 7 low-side	
41	Digital output 8 low-side	
42	Digital output 9 low-side	
43	Digital output 10 low-side	
44	Digital output 11 low-side	
45	Digital output 12 low-side	
46	Digital output 13 low-side	
47	Digital output 14 low-side	
48	Digital output 15 low-side	
49	Digital output 16 low-side	
50	External power supply	24 V, 4A fuse (FH12-P)

## 6.5 PROFIBUS interfaces


### 6.5.1 X15A and X15B PROFIBUS interface

**Description** The interfaces PROFIBUS X15A and X15B are universal field buses which enable communication between devices from different manufacturers without special interface adaptations. Data exchange is carried out on a master-slave basis.

**Power supply** The power can be supplied either directly from an external source, or by jumpering the internal voltage on X55.


**Necessary equipment**

- Male insert, HAN 8D



**Fig. 6-17: Contact diagram, X15A, view from contact side**

- Cable clamping range: Ø9 ... Ø14.7 mm
- Recommended connecting cable: Multibus cable
- 



**Fig. 6-18: Contact diagram, X15B, view from contact side**

- Cable clamping range: Ø9 ... Ø14.7 mm
- Recommended connecting cable: Multibus cable

#### Connector pin allocation X15A

Pin	Description
1	0 V
2	Not assigned
3	Not assigned
4	+24 V DC
5	PE
6	Not assigned
7	PROFI A
8	PROFI B
9-17	Not assigned

#### Connector pin allocation X15B

Pin	Description
1	0 V
2	Not assigned
3	Not assigned
4	+24 V DC
5	PE
6	Not assigned
7	PROFI A
8	PROFI B
9-17	Not assigned




The PROFIBUS interface must be configured with Work Visual.

### 6.5.2 X61 PROFIBUS master

**Description** PROFIBUS is a universal field bus which enables communication between devices from different manufacturers without special interface adaptations. Data exchange is carried out on a master-slave basis.

**Necessary equipment**

- Male insert, HAN 8D



**Fig. 6-19: Contact diagram, view from contact side**

- Cable clamping range: Ø9 ... Ø14.7 mm
- Recommended connecting cable: Multibus cable

**Connector pin allocation X61**

Pin	Description
11	PROFI A
6	PROFI B
5	PE
4	+24 V
1	0 V
3	24 V
2	0 V
7	Not assigned
8	Not assigned
9	Not assigned
10	Not assigned
12	Not assigned
13	Not assigned
14	Not assigned
15	Not assigned
16	Not assigned
17	Not assigned


## 6.6 Euromap interfaces

### 6.6.1 X67.1 and X67.2 VARAN slave interfaces

**Description** Interfaces X67.1 and X67.2 are used to connect the robot controller to a VARAN bus system.

**Necessary equipment**

- RJ45 connector

**Fig. 6-20: RJ-45 pin assignment**

- Recommended connecting cable: Ethernet-compatible, min. category CAT 5e
- Maximum cable cross-section: AWG22

**Connector pin allocation X67.1**

Pin	Description
1	TD+ VARAN IN
2	TD- VARAN IN
3	RD+ VARAN IN
6	RD- VARAN IN
-	PE

**Connector pin allocation X67.2**

Pin	Description
1	TD+ VARAN OUT
2	TD- VARAN OUT
3	RD+ VARAN OUT
6	RD- VARAN OUT
-	PE


**6.7 Fast Measurement****6.7.1 X33 Fast Measurement inputs****Description**

Fast measurement is activated with \$MEAS\_PULSE by means of an interrupt. When the interrupt is activated, \$MEAS\_PULSE must have the value "false", otherwise an acknowledgement message is generated and the program is stopped.

**Necessary equipment**

- Circular connector, M23, 9-pole, P-part





**Fig. 6-21: Contact diagram, X33, view from contact side**

- Cable clamping range: Ø6 ... Ø10 mm
- Recommended cable cross-section: 1 mm<sup>2</sup>

#### Connector pin allocation X33


Pin	Description
1	Fast Measurement 1
2	Fast Measurement 2
3	Fast Measurement 3
4	Fast Measurement 4
5	Spare
6	+24 V-P
7	GND-Input
8	0 V-P

#### 6.7.1.1 Power supply for Fast Measurement

##### Internal power supply

If the sensors for Fast Measurement are supplied with power by the robot controller (pin 6 +24V-P, pin 8 GND-P), pins 7 and 8 in the customer's mating piece for X33 must be connected. In this way, the reference ground for the Fast Measurement inputs (pin 7 GND input) is connected to the power supply ground of the sensors (pin 8 GND-P).

The diagram ( >>> Fig. 6-22 ) illustrates the internal voltage supply.




**Fig. 6-22: Internal power supply for "Fast Measurement"**

- |            |  |
|------------|--|
| 1 Sensor 1 | 4 Sensor 4   |
| 2 Sensor 2 | 5 Jumper between GND-INPUT and 0V-P in connector X33 |
| 3 Sensor 3 |  |

### External power supply

If the sensors for Fast Measurement are supplied externally with power (not via X33 of the robot controller), the reference ground of the sensors must be connected to pin 7 GND-Input.



**Fig. 6-23: External power supply for “Fast Measurement”**

- |   |          |   |                           |
|---|----------|---|---------------------------|
| 1 | Sensor 1 | 4 | Sensor 4                  |
| 2 | Sensor 2 | 5 | 0 V external to GND-INPUT |
| 3 | Sensor 3 | 6 | 24 V DC external          |


### 6.7.2 X60 PickControl interface

#### Description

Fast measurement is activated with \$MEAS\_PULSE by means of an interrupt. When the interrupt is activated, \$MEAS\_PULSE must have the value “false”, otherwise an acknowledgement message is generated and the program is stopped.

#### Necessary equipment

- Circular connector, 19-pole



**Fig. 6-24: Contact diagram, view from contact side**

- Cable clamping range: Ø9 ... Ø14.7 mm
- Recommended cable cross-section: 0.5 mm<sup>2</sup>

#### Connector pin allocation X60

Pin	Description
1	Fast Measurement 1
2	Fast Measurement 2
3	Fast Measurement 3
4	Fast Measurement 4
5	Spare
	Fast Measurement 5
8	GND-Input


Pin	Description
7	+24 V-P
9	0 V-P
10	Digital output 1
11	0 V
13	0 V
14	Digital output 3
15	Digital output 2
16	0 V
17	0 V
18	Digital output 4

**Digital outputs** 0.5 A per output, 24 V power supply

### 6.7.2.1 Power supply for Fast Measurement X60

#### Internal power supply

If the sensors for Fast Measurement are supplied with power by the robot controller (pin 7 +24V-P, pin 9 GND-P), pins 8 and 9 in the customer's mating piece for X60 must be connected. In this way, the reference ground for the Fast Measurement inputs (pin 8 GND input) is connected to the power supply ground of the sensors (pin 9 GND-P).




**Fig. 6-25: Internal power supply for “Fast Measurement” X60**

- |            |  |
|------------|--|
| 1 Sensor 1 | 4 Sensor 4   |
| 2 Sensor 2 | 5 Sensor 5   |
| 3 Sensor 3 | 6 Jumper between GND-INPUT and 0V-P in connector X60 |

#### External power supply

If the sensors for Fast Measurement are supplied externally with power (not via X60 of the robot controller), the reference ground of the sensors must be connected to pin 8 GND-Input.



**Fig. 6-26: External power supply for “Fast Measurement”**

- |   |          |   |                           |
|---|----------|---|---------------------------|
| 1 | Sensor 1 | 5 | Sensor 5                  |
| 2 | Sensor 2 | 6 | 0 V external to GND-INPUT |
| 3 | Sensor 3 | 7 | 24 V DC external          |
| 4 | Sensor 4 |   |                           |

## 6.8 X28 Drive box interface for external axes interface

### Description

Interface X28 in the drive box is for the connection of an optional drive box for external axes.

### Connector pin allocation X28

Pin	Description
1	+24 V PS1
2	GND
3	Not assigned
4	Not assigned
5	+24 V network
6	GND
7	Not assigned
8	Not assigned
9	TPF0_P
10	TPFI_P
11	TPF0_N
12	TPFI_N
-	PE

## 6.9 X70 and X71 RoboTeam interface

### Connector pin allocation X70 RoboTeam IN

Pin	Description
1	TPFO_P
2	TPFO_N
3	TPFI_P
6	TPFI_N
4	C+
5	C-

Pin	Description
7	D+
8	D-

**Connector pin  
allocation X71  
RoboTeam OUT**

Pin	Description
1	TPFO_P
2	TPFO_N
3	TPFI_P
6	TPFI_N
4	C+
5	C-
7	D+
8	D-

## 6.10 Performance level

The safety functions of the robot controller conform to Category 3 and Performance Level d according to EN ISO 13849-1.

### 6.10.1 PFH values of the safety functions

The safety values are based on a service life of 20 years.

The PFH value classification of the controller is only valid if the E-STOP device is tested at least once every 12 months.

When evaluating system safety functions, it must be remembered that the PFH values for a combination of multiple controllers may have to be taken into consideration more than once. This is the case for RoboTeam systems or higher-level hazard areas. The PFH value determined for the safety function at system level must not exceed the limit for PL d.

The PFH values relate to the specific safety functions of the different controller variants.

Safety function groups:

- Standard safety functions
  - Operating mode selection
  - Operator safety
  - EMERGENCY STOP device
  - Enabling device
  - External safe operational stop
  - External safety stop 1
  - External safety stop 2
  - Velocity monitoring in T1
- Safety functions of KUKA Safe Robot Technology (optional)
  - Monitoring of axis spaces
  - Monitoring of Cartesian spaces
  - Monitoring of axis velocity
  - Monitoring of Cartesian velocity
  - Monitoring of axis acceleration
  - Safe operational stop
  - Tool monitoring

Overview of controller variant PFH values:

Robot controller variant	PFH value
KR C4 compact	$< 6.37 \times 10^{-8}$



For controller variants that are not listed here, please contact KUKA Roboter GmbH.

## 7 Troubleshooting

### 7.1 IOB board LED display

#### Overview




Fig. 7-1: IOB board LED display

Item	Designation	Color	Description	Remedy
1	PWRS/3.3V	Green	On = power supply present	-
			Off = no supply voltage present	Check fuse: <ul style="list-style-type: none"> <li>For internal power supply, check fuse F301 on CCU</li> <li>For external power supply, check fuse via X55 customer power supply</li> </ul>
2	Fuse LEDs The LEDs indicate the status of the fuses.	Red	On = fuse defective	Exchange defective fuse
			Off = fuse OK	-
3	L/A	Green	On = physical connection, network cable is plugged in	-
			Off = no physical connection. Network cable is not plugged in	
			Flashing = data traffic on the line	





## 8 KUKA Service

### 8.1 Requesting support

<b>Introduction</b>	This documentation provides information on operation and operator control, and provides assistance with troubleshooting. For further assistance, please contact your local KUKA subsidiary.
<b>Information</b>	<p><b>The following information is required for processing a support request:</b></p> <ul style="list-style-type: none"> <li>■ Description of the problem, including information about the duration and frequency of the fault</li> <li>■ As comprehensive information as possible about the hardware and software components of the overall system</li> </ul> <p>The following list gives an indication of the information which is relevant in many cases:</p> <ul style="list-style-type: none"> <li>■ Model and serial number of the kinematic system, e.g. the manipulator</li> <li>■ Model and serial number of the controller</li> <li>■ Model and serial number of the energy supply system</li> <li>■ Designation and version of the system software</li> <li>■ Designations and versions of other software components or modifications</li> <li>■ Diagnostic package KRCDiag</li> </ul> <p>Additionally for KUKA Sunrise: Existing projects including applications For versions of KUKA System Software older than V8: Archive of the software (KRCDiag is not yet available here.)</p> <ul style="list-style-type: none"> <li>■ Application used</li> <li>■ External axes used</li> </ul>

### 8.2 KUKA Customer Support

<b>Availability</b>	KUKA Customer Support is available in many countries. Please do not hesitate to contact us if you have any questions.
<b>Argentina</b>	<p>Ruben Costantini S.A. (Agency)  Luis Angel Huergo 13 20  Parque Industrial  2400 San Francisco (CBA)  Argentina  Tel. +54 3564 421033  Fax +54 3564 428877  ventas@costantini-sa.com</p>
<b>Australia</b>	<p>KUKA Robotics Australia Pty Ltd  45 Fennell Street  Port Melbourne VIC 3207  Australia  Tel. +61 3 9939 9656  info@kuka-robotics.com.au  www.kuka-robotics.com.au</p>

<b>Belgium</b>	<p>KUKA Automatisering + Robots N.V.  Centrum Zuid 1031  3530 Houthalen  Belgium  Tel. +32 11 516160  Fax +32 11 526794  <a href="mailto:info@kuka.be">info@kuka.be</a>  <a href="http://www.kuka.be">www.kuka.be</a></p>
<b>Brazil</b>	<p>KUKA Roboter do Brasil Ltda.  Travessa Claudio Armando, nº 171  Bloco 5 - Galpões 51/52  Bairro Assunção  CEP 09861-7630 São Bernardo do Campo - SP  Brazil  Tel. +55 11 4942-8299  Fax +55 11 2201-7883  <a href="mailto:info@kuka-roboter.com.br">info@kuka-roboter.com.br</a>  <a href="http://www.kuka-roboter.com.br">www.kuka-roboter.com.br</a></p>
<b>Chile</b>	<p>Robotec S.A. (Agency)  Santiago de Chile  Chile  Tel. +56 2 331-5951  Fax +56 2 331-5952  <a href="mailto:robotec@robotec.cl">robotec@robotec.cl</a>  <a href="http://www.robotec.cl">www.robotec.cl</a></p>
<b>China</b>	<p>KUKA Robotics China Co., Ltd.  No. 889 Kungang Road  Xiaokunshan Town  Songjiang District  201614 Shanghai  P. R. China  Tel. +86 21 5707 2688  Fax +86 21 5707 2603  <a href="mailto:info@kuka-robotics.cn">info@kuka-robotics.cn</a>  <a href="http://www.kuka-robotics.com">www.kuka-robotics.com</a></p>
<b>Germany</b>	<p>KUKA Roboter GmbH  Zugspitzstr. 140  86165 Augsburg  Germany  Tel. +49 821 797-1926  Fax +49 821 797-41 1926  <a href="mailto:Hotline.robotics.de@kuka.com">Hotline.robotics.de@kuka.com</a>  <a href="http://www.kuka-roboter.de">www.kuka-roboter.de</a></p>

**France**  
KUKA Automatisme + Robotique SAS  
Techvallée  
6, Avenue du Parc  
91140 Villebon S/Yvette  
France  
Tel. +33 1 6931660-0  
Fax +33 1 6931660-1  
commercial@kuka.fr  
www.kuka.fr

**India**  
KUKA Robotics India Pvt. Ltd.  
Office Number-7, German Centre,  
Level 12, Building No. - 9B  
DLF Cyber City Phase III  
122 002 Gurgaon  
Haryana  
India  
Tel. +91 124 4635774  
Fax +91 124 4635773  
info@kuka.in  
www.kuka.in

**Italy**  
KUKA Roboter Italia S.p.A.  
Via Pavia 9/a - int.6  
10098 Rivoli (TO)  
Italy  
Tel. +39 011 959-5013  
Fax +39 011 959-5141  
kuka@kuka.it  
www.kuka.it

**Japan**  
KUKA Robotics Japan K.K.  
YBP Technical Center  
134 Godo-cho, Hodogaya-ku  
Yokohama, Kanagawa  
240 0005  
Japan  
Tel. +81 45 744 7691  
Fax +81 45 744 7696  
info@kuka.co.jp

**Canada**  
KUKA Robotics Canada Ltd.  
6710 Maritz Drive - Unit 4  
Mississauga  
L5W 0A1  
Ontario  
Canada  
Tel. +1 905 670-8600  
Fax +1 905 670-8604  
info@kukarobotics.com  
www.kuka-robotics.com/canada

<b>Korea</b>	<p>KUKA Robotics Korea Co. Ltd.  RIT Center 306, Gyeonggi Technopark  1271-11 Sa 3-dong, Sangnok-gu  Ansan City, Gyeonggi Do  426-901  Korea  Tel. +82 31 501-1451  Fax +82 31 501-1461  <a href="mailto:info@kukakorea.com">info@kukakorea.com</a></p>
<b>Malaysia</b>	<p>KUKA Robot Automation (M) Sdn Bhd  South East Asia Regional Office  No. 7, Jalan TPP 6/6  Taman Perindustrian Puchong  47100 Puchong  Selangor  Malaysia  Tel. +60 (03) 8063-1792  Fax +60 (03) 8060-7386  <a href="mailto:info@kuka.com.my">info@kuka.com.my</a></p>
<b>Mexico</b>	<p>KUKA de México S. de R.L. de C.V.  Progreso #8  Col. Centro Industrial Puente de Vigas  Tlalnepantla de Baz  54020 Estado de México  Mexico  Tel. +52 55 5203-8407  Fax +52 55 5203-8148  <a href="mailto:info@kuka.com.mx">info@kuka.com.mx</a>  <a href="http://www.kuka-robotics.com/mexico">www.kuka-robotics.com/mexico</a></p>
<b>Norway</b>	<p>KUKA Sveiseanlegg + Roboter  Sentrumsvegen 5  2867 Hov  Norway  Tel. +47 61 18 91 30  Fax +47 61 18 62 00  <a href="mailto:info@kuka.no">info@kuka.no</a></p>
<b>Austria</b>	<p>KUKA Roboter CEE GmbH  Gruberstraße 2-4  4020 Linz  Austria  Tel. +43 7 32 78 47 52  Fax +43 7 32 79 38 80  <a href="mailto:office@kuka-roboter.at">office@kuka-roboter.at</a>  <a href="http://www.kuka.at">www.kuka.at</a></p>

**Poland** KUKA Roboter CEE GmbH Poland  
Spółka z ograniczoną odpowiedzialnością  
Oddział w Polsce  
Ul. Porcelanowa 10  
40-246 Katowice  
Poland  
Tel. +48 327 30 32 13 or -14  
Fax +48 327 30 32 26  
ServicePL@kuka-roboter.de

**Portugal** KUKA Robots IBÉRICA, S.A.  
Rua do Alto da Guerra n° 50  
Armazém 04  
2910 011 Setúbal  
Portugal  
Tel. +351 265 729 780  
Fax +351 265 729 782  
info.portugal@kukapt.com  
www.kuka.com

**Russia** KUKA Robotics RUS  
Werbnaja ul. 8A  
107143 Moskau  
Russia  
Tel. +7 495 781-31-20  
Fax +7 495 781-31-19  
info@kuka-robotics.ru  
www.kuka-robotics.ru

**Sweden** KUKA Svetsanläggningar + Robotar AB  
A. Odhners gata 15  
421 30 Västra Frölunda  
Sweden  
Tel. +46 31 7266-200  
Fax +46 31 7266-201  
info@kuka.se

**Switzerland** KUKA Roboter Schweiz AG  
Industriestr. 9  
5432 Neuenhof  
Switzerland  
Tel. +41 44 74490-90  
Fax +41 44 74490-91  
info@kuka-roboter.ch  
www.kuka-roboter.ch

<b>Spain</b>	<p>KUKA Robots Ibérica, S.A.  Pol. Industrial  Torrent de la Pastera  Carrer del Bages s/n  08800 Vilanova i la Geltrú (Barcelona)  Spain  Tel. +34 93 8142-353  comercial@kukarob.es</p>
<b>South Africa</b>	<p>Jendamark Automation LTD (Agency)  76a York Road  North End  6000 Port Elizabeth  South Africa  Tel. +27 41 391 4700  Fax +27 41 373 3869  www.jendamark.co.za</p>
<b>Taiwan</b>	<p>KUKA Robot Automation Taiwan Co., Ltd.  No. 249 Pujong Road  Jungli City, Taoyuan County 320  Taiwan, R. O. C.  Tel. +886 3 4331988  Fax +886 3 4331948  info@kuka.com.tw  www.kuka.com.tw</p>
<b>Thailand</b>	<p>KUKA Robot Automation (M)SdnBhd  Thailand Office  c/o Maccall System Co. Ltd.  49/9-10 Soi Kingkaew 30 Kingkaew Road  Tt. Rachatheva, A. Bangpli  Samutprakarn  10540 Thailand  Tel. +66 2 7502737  Fax +66 2 6612355  atika@ji-net.com  www.kuka-roboter.de</p>
<b>Czech Republic</b>	<p>KUKA Roboter Austria GmbH  Organisation Tschechien und Slowakei  Sezemická 2757/2  193 00 Praha  Horní Počernice  Czech Republic  Tel. +420 22 62 12 27 2  Fax +420 22 62 12 27 0  support@kuka.cz</p>

**Hungary** KUKA Robotics Hungaria Kft.  
Fő út 140  
2335 Taksony  
Hungary  
Tel. +36 24 501609  
Fax +36 24 477031  
info@kuka-robotics.hu

**USA** KUKA Robotics Corporation  
51870 Shelby Parkway  
Shelby Township  
48315-1787  
Michigan  
USA  
Tel. +1 866 873-5852  
Fax +1 866 329-5852  
info@kukarobotics.com  
www.kukarobotics.com

**UK** KUKA Robotics UK Ltd  
Great Western Street  
Wednesbury West Midlands  
WS10 7LL  
UK  
Tel. +44 121 505 9970  
Fax +44 121 505 6589  
service@kuka-robotics.co.uk  
www.kuka-robotics.co.uk





## Index

### Numbers

0 V reference point 33

### A

Accessories 9

### B

Beckhoff modules 26

### C

CCU\_SR 6

CIB\_SR 6

CIP Safety 6

Connecting cables 9

Connection panel 9

Connection panel, overview 10

Connector pin allocation 26

Control PC 9

### D

Data cables 10

Description of the industrial robot 9

DeviceNet interfaces X14 24

DeviceNet master 24

DeviceNet Slave IN and OUT 25

DeviceNet X14A 24

DeviceNet X14C 25

DeviceNet X14D 25

Digital I/O interfaces 26

Digital I/O modules 16/16 13, 26

Digital I/O modules 16/16/4 14, 28

Digital input 1 33, 34, 36

Digital input 10 33, 34, 36

Digital input 11 33, 34, 36

Digital input 12 33, 34, 36

Digital input 13 33, 34, 36

Digital input 14 33, 34, 36

Digital input 15 33, 34, 36

Digital input 16 33, 34, 36

Digital input 18 high-side 34, 37

Digital input 19 high-side 34, 37

Digital input 2 33, 34, 36

Digital input 20 high-side 34, 37

Digital input 21 high-side 34, 37

Digital input 22 high-side 34, 37

Digital input 23 high-side 34, 37

Digital input 24 high-side 34, 37

Digital input 25 high-side 34, 37

Digital input 26 high-side 34, 37

Digital input 27 high-side 34, 37

Digital input 28 high-side 34, 37

Digital input 29 high-side 34, 37

Digital input 3 33, 34, 36

Digital input 30 high-side 34, 37

Digital input 31 high-side 34, 37

Digital input 32 high-side 34, 37

Digital input 4 33, 34, 36

Digital input 5 33, 34, 36

Digital input 6 33, 34, 36

Digital input 7 33, 34, 36

Digital input 8 33, 34, 36

Digital input 9 33, 34, 36

Digital output 1 33

Digital output 1 low-side 35, 37

Digital output 10 33

Digital output 10 low-side 35, 37

Digital output 11 33

Digital output 11 low-side 35, 37

Digital output 12 33

Digital output 12 low-side 35, 37

Digital output 13 33

Digital output 13 low-side 35, 37

Digital output 14 33

Digital output 14 low-side 35, 37

Digital output 15 33

Digital output 15 low-side 35, 37

Digital output 16 33

Digital output 16 low-side 35, 37

Digital output 17 33

Digital output 17 high-side 34, 37

Digital output 18 33

Digital output 19 33

Digital output 2 33

Digital output 2 low-side 35, 37

Digital output 20 33

Digital output 3 33

Digital output 3 low-side 35, 37

Digital output 4 33

Digital output 4 low-side 35, 37

Digital output 5 33

Digital output 5 low-side 35, 37

Digital output 6 33

Digital output 6 low-side 35, 37

Digital output 7 33

Digital output 7 low-side 35, 37

Digital output 8 33

Digital output 8 low-side 35, 37

Digital output 9 33

Digital output 9 low-side 35, 37

Documentation, industrial robot 5

Drive box X28 44

Dual NIC card 6

### E

EA 6

EDS 6

EL1889 31

EL2889 32

EMC 6

EMD 6

EtherCAT bridge, external power supply 22

EtherCAT interfaces 23

Euromap interfaces 39

External power supply 22

External power supply X33 42

External power supply X55 22

External power supply X60 43

External voltage 17

## F

Fast Measurement, interfaces 40

Fast Measurement, X33 40

## G

GND 34, 37

## I

Industrial robot 9

Infeed 10

Input current 17

Inputs, 16-channel 31

Intended use 7

Interface X70 44

Interface X71 44

Interface, drive box X28 44

Interfaces, discrete 21

Interfaces, KR C4 compact 10

Internal power supply X33 41

Internal power supply X60 43

Introduction 5

IOB board LED display 47

IOB board LED display, overview 47

## K

KCB 6

KEB 6

KEI 6

KLI 6

KOI 6

KONI 6

KPC 6

KPP\_SR 6

KRL 6

KSB 6

KSI 6

KSP\_SR 6

KSS 6

KUKA Customer Support 49

KUKA smartPAD cable 10

## M

Manipulator 6, 9

Motor cables 10

## O

Options 9

Output type 17

outputs, 16-channel 32

Overview of robot controller 9

## P

PE cables 10

PELV power supply unit 17

Performance level 45

Peripheral cables 10

PFH values 45

PickControl X60 42

PL 45

Planning 21

PMB\_SR 6

Power cable 10

Power supply for Fast Measurement 41

Power supply for Fast Measurement X60 43

Power supply, external 22, 35, 37

Power supply, external 24 V 14

Power supply, X15A and X15B 37

Power unit 9

Product description 9

PROFIBUS interface X15A 37

PROFIBUS interface X15B 37

PROFIBUS master X61 39

PROFIBUS, interfaces 37

Purpose 7

## R

RDC 6

Reference switch, X42 21

Robot controller 9

RoboTeam interface 44

## S

Safely isolated 17

SafeOperation, X42 21

Safety 19

Safety instructions 5

Safety logic 9

Safety options, interfaces 21

SATA connections 6

Service, KUKA Roboter GmbH 49

Signal voltage 0 17

Signal voltage 1 17

Software 9

Support request 49

Switch, external power supply 22

## T

Target group 7

Teach pendant 9

Technical data 17

Terms used 6

Training 7

Troubleshooting 47

## U

USB 6

## V

VARAN slave, external power supply 22

Voltage 17

## W

Warnings 5

## X

X14A, connector pin allocation 25

X15A, connector pin allocation 38

X15B, connector pin allocation 38

X28, connector pin allocation 44

X33, connector pin allocation 41  
X33, Fast Measurement 40  
X42, reference switch 21  
X60 PickControl 42  
X60, connector pin allocation 42  
X61 39  
X61, connector pin allocation 39  
X67.1, EtherCAT bridge 23  
X67.1, VARAN 39  
X67.2, EtherCAT bridge 23  
X67.2, VARAN 39  
X70, connector pin allocation 44  
X71, connector pin allocation 45



